

## POSITION Fersa    MS-13-185	Differentials	<b>(</b>
Bevel pinion front H 715334/H 715311  Bevel pinion rear F 19063  Bevel pinion pilot 9278/9220  Differential right JHM 720249/JHM 720210  Differential left 64450/64700  U177  Bevel pinion pilot F 19063  Differential right 32021 XF  Differential left 32021 XF  U180  Bevel pinion front H 715334/H 715311  Bevel pinion rear 9278/9220  Bevel pinion pilot F 19063  Differential right JHM 720249/JHM 720210	POSITION	Fersa
Bevel pinion rear   F 19063	MS-13-185	
Bevel pinion pilot   9278/9220     Differential right   JHM 720249/JHM 720210     Differential left   64450/64700      U177	Bevel pinion front	H 715334/H 715311
Differential right Differential left Differential left Differential left Differential left Differential left Differential right Differential left Differential right Differential right Differential right Differential left Differential right Differential right Differential right Differential right	Bevel pinion rear	F 19063
Differential left	Bevel pinion pilot	9278/9220
U177  Bevel pinion pilot F 19063  Differential right 32021 XF  Differential left 32021 XF  U180  Bevel pinion front H 715334/H 715311  Bevel pinion rear 9278/9220  Bevel pinion pilot F 19063  Differential right JHM 720249/JHM 720210	Differential right	JHM 720249/JHM 720210
Bevel pinion pilot	Differential left	64450/64700
Bevel pinion pilot		
Differential right   32021 XF	U177	
Differential left 32021 XF  U180  Bevel pinion front H 715334/H 715311 Bevel pinion rear 9278/9220 Bevel pinion pilot F 19063 Differential right JHM 720249/JHM 720210	Bevel pinion pilot	F 19063
U180  Bevel pinion front H 715334/H 715311  Bevel pinion rear 9278/9220  Bevel pinion pilot F 19063  Differential right JHM 720249/JHM 720210	Differential right	32021 XF
Bevel pinion front         H 715334/H 715311           Bevel pinion rear         9278/9220           Bevel pinion pilot         F 19063           Differential right         JHM 720249/JHM 720210	Differential left	32021 XF
Bevel pinion front         H 715334/H 715311           Bevel pinion rear         9278/9220           Bevel pinion pilot         F 19063           Differential right         JHM 720249/JHM 720210		
Bevel pinion rear 9278/9220 Bevel pinion pilot F 19063 Differential right JHM 720249/JHM 720210	U180	
Bevel pinion pilot F 19063 Differential right JHM 720249/JHM 720210	Bevel pinion front	H 715334/H 715311
Differential right JHM 720249/JHM 720210	Bevel pinion rear	9278/9220
g and a second s	Bevel pinion pilot	F 19063
Differential left 64450/64700	Differential right	JHM 720249/JHM 720210
	Differential left	64450/64700

Wheel End		
AXLE	POSITION	Fersa
EuroCargo		
Front axle	Inboard	33019 F
Front axle	Outboard	32018 XF
Front axle	Outboard	32021 XF
Rear axle	Hub Unit	F 15122
Rear axle	Inboard	30215 F
Rear axle	Inboard	30218 F
Rear axle	Inboard	33019 F
Rear axle	Outboard	33118 F
Rear axle	Outboard	30221 F
Rear axle	Outboard	32021 XF

wheel End		
AXLE	POSITION	Fersa
EuroStar		
Rear axle	Hub Unit	F 15122
Rear axle	Inboard	32220 F
Rear axle	Inboard	32218 F
Rear axle	Inboard	32221 F
Rear axle	Outboard	32219 F
Rear axle	Outboard	32217 F
EuroTech		
Front axle	Inboard	33019 F
Front axle	Outboard	32021 XF
Rear axle	Hub Unit	F 15122
Rear axle	Inboard	32218 F
Rear axle	Inboard	32221 F
Rear axle	Inboard	32220 F
Rear axle	Inboard	30221 F
Rear axle	Outboard	32217 F
Rear axle	Outboard	32219 F
Rear axle	Outboard	32024 XF
EuroTrakker		
Front axle	Inboard	33019 F
Front axle	Outboard	32021 XF
Rear axle	Inboard	30221 F
Rear axle	Outboard	32024 XF
Stralis		
Rear axle	Hub Unit	F 15122
Trakker		
Front axle	Inboard	33019 F
Front axle	Outboard	32021 XF
Rear axle	Inboard	30221 F
Rear axle	Outboard	32024 XF





Gearboxes	
POSITION	Fersa
ZF	
S5-420	
Counter shaft front	2580/2520
Counter shaft rear	2580/2520
Main shaft front	CONE F 15084
Input shaft front	28580/28521
6S-850	
Input shaft front	F 18054
Main shaft rear	6309 2RS
Counter shaft front	344/332
Counter shaft rear	2789/2729
8S180	
Input shaft front	47490/47420
Main shaft front	CONE 4395
Main shaft rear	HM 807046/HM 807010 BT
Counter shaft front	JF 4049/JF 4010
Counter shaft rear	33889/33822
Output shaft front	F 18052
9S-109	
Input shaft front	33262 A/33461
Main shaft front	CONE F 15110
Main shaft rear	F 15212
Counter shaft front	33208 F
Counter shaft rear	33889/33822
Output shaft front	F 18052

Gearboxes	
POSITION	Fersa
ZF	
16S-151	
Input shaft front	30217 F
Main shaft front	CONE 4395
Main shaft rear	F 15246
Output shaft front	F 18052
Output shaft rear	6218 C3
Counter shaft front	F 15047
Counter shaft front	5395/5335
Counter shaft rear	4580/4535
Main shaft intermediate	F 19061
<u> </u>	
16S-181	
Input shaft front	30217 F
Main shaft front	CONE 4395
Main shaft rear	F 15191
Output shaft rear	6218 C3
Counter shaft front	5395/5335
Counter shaft rear	5395/5335
16S-221	
Input shaft front	30217 F
Main shaft front	CONE 4395
Main shaft rear	F 15191
Output shaft rear	6218 C3
Counter shaft front	5395/5335
Counter shaft rear	5395/5335
Main shaft intermediate	F 19062
Output shaft front	6218 C3

